




NI :			NI-DIAG14 .CE2 for JAPAN-market vehicles	
DDL1 DIAG-NI14	Turn ignition On. (Do not start the engine.)			
1 : Rx	14 :	Connect the #6 & #7 PINs over 2 seconds		
2 : Tx	and OPEN it.			
4 :	6 : CHK	DTCs will be displayed on the MIL. (The light will blink.)		
8 : (-)	7 : IGN			
9 : CLK				
12 : SCO				
13 : SCI				
CHK (6 :) と IGN (7 :) を				
2秒以上 短絡後、開放し、CHECK ENG.Light 点滅回数を読む				