

OBD II SYSTEMS

YEAR	DTC NO.	DESCRIPTION
1995-98 OBD II	P0000	No Failure Detected
	P0100	MAF Sensor Circuit Malfunction
	P0105	Absolute Pressure Sensor Malfunction
	P0110	IAT Sensor circuit malfunction
	P0115	ECT circuit malfunction
	P0120	TPS circuit malfunction
	P0125	Coolant temp. Sensor Circuit Malfunction, no Closed Loop Fuel Control
	P0130	Front (H)O2 Sensor Circuit Malfunction, no Closed Loop
	P0131	Front HO2 Sensor, Lean Shift Monitor
	P0132	Front HO2 Sensor, Rich Shift Monitor
	P0133	Front HO2 Sensor, Response Monitor
	P0134	Front HO2 Sensor, Excessively High Voltage
	P0135	Front HO2S Heater Circuit Malfunction (Right Bank)
	P0136	Rear HO2 Sensor Circuit Malfunction
	P0137	Rear HO2 Sensor, Minimum Voltage Monitor
	P0138	Rear HO2 Sensor, Maximum Voltage Monitor
	P0139	Rear HO2 Sensor, Response Monitor
	P0140	Rear HO2 Sensor, Excessively High Voltage
	P0141	Rear HO2 Sensor Heater Circuit Malfunction
	P0150	Front HO2 Sensor Circuit, No Closed Loop Control (Left Bank)
	P0151	Front HO2 Sensor, Lean Shift Monitor (Left Bank)
	P0152	Front HO2 Sensor, Rich Shift Monitor (Left Bank)
	P0153	Front HO2 Sensor, Response Monitor (Left Bank)
	P0154	Front HO2 Sensor, Excessively High Voltage (Left Bank)
	P0155	Front HO2 Sensor Heater Circuit Malfunction, Left Bank
	P0156	Rear HO2 Sensor Circuit Malfunction (Left Bank)
	P0157	Rear HO2 Sensor, Minimum Voltage Monitor (Left Bank)
	P0158	Rear HO2 Sensor, Maximum Voltage Monitor (Left Bank)
	P0159	Rear HO2 Sensor, Response Monitor (Left Bank)
	P0160	Rear HO2 Sensor, Excessively High Voltage (Left Bank)
	P0161	Rear HO2 Sensor Heater Circuit Malfunction, Left Bank
	P0170	Fuel Injection System Malfunction (Right Bank)
	P0171	Fuel System Malfunction, Lean Condition (Right Bank)
	P0172	Fuel System Malfunction, Rich Condition (Right Bank)
P0173	Fuel Injection System Malfunction (Left Bank)	
P0174	Fuel System Malfunction, Lean Condition (Left Bank)	
P0175	Fuel System Malfunction, Rich Condition (Left Bank)	
P0180	Fuel Tank Temp. Sensor Circuit Malfunction	

NISSAN DTCs (CONT.)

YEAR	DTC NO.	DESCRIPTION
1995-98 OBD II	P0300	Random Misfire Detected
	P0301	Cylinder No. 1, Misfire Detected
	P0302	Cylinder No. 2, Misfire Detected
	P0303	Cylinder No. 3, Misfire Detected
	P0304	Cylinder No. 4, Misfire Detected
	P0305	Cylinder No. 5, Misfire Detected
	P0306	Cylinder No. 6, Misfire Detected
	P0325	Knock Sensor Circuit Malfunction
	P0335	Crankshaft Position Sensor Circuit Malfunction
	P0340	Camshaft Position Sensor Circuit Malfunction
	P0400	EGR System Malfunction
	P0402	EGRC-BPT Valve Malfunction
	P0420	Three-way Catalyst System Malfunction (Right Bank)
	P0430	Three-way Catalyst System Malfunction (Left Bank)
	P0440	EVAP System, Small Leak Detected
	P0443	EVAP Purge Control Valve Circuit Malfunction
	P0446	EVAP Vent Control Valve, Circuit Malfunction
	P0450	EVAP System, Pressure Sensor Malfunction
	P0500	Vehicle Speed Sensor Malfunction
	P0505	IAC Valve-AAC, System Malfunction
	P0510	Closed Throttle Sensor Idle Switch Malfunction
	P0600	Signal Circuit from A/T to ECM Malfunction
	P0605	ECM Malfunction
	P0705	Park/Neutral (Inhibitor) Switch Malfunction
	P0710	Trans. Fluid Temp. Sensor Out of Range
	P0720	A/T VSS Circuit Malfunction
	P0725	Engine RPM signal Malfunction
	P0731	A/T 1st Gear Shift Signal Malfunction
	P0732	A/T 2nd Gear Shift Signal Malfunction
	P0733	A/T 3rd Gear Shift Signal Malfunction
	P0734	A/T 4th Gear Signal or TCC Malfunction
	P0740	TCC Solenoid Valve Malfunction
	P0744	A/T TCC Signal, Improper Lock-Up Operation
	P0745	Line Pressure Solenoid Valve Malfunction
	P0750	Shift Solenoid A, Malfunction
	P0755	Shift Solenoid B, Malfunction
	P1105	MAP/BARO Switch Solenoid Valve Malfunction
	P1110	Valve Timing Control Valve System Malfunction

YEAR	DTC NO.	DESCRIPTION
1995-98 OBD II	P1130	Swirl Control Solenoid Valve Malfunction
	P1150	W/G Control Solenoid Valve (Right Bank)
	P1155	W/G Control Solenoid Valve (Left Bank)
	P1160	Turbo Boost Sensor Circuit Malfunction
	P1165	Swirl Control Valve Vacuum Check Switch Malfunction
	P1168	Front HO2 Sensor Circuit Malfunction, no Closed Loop (Left Bank)
	P1220	Fuel Pump Control Module Circuit Malfunction
	P1320	Ignition Signal Primary Circuit Malfunction
	P1335	CKP Sensor (Reference) Circuit Malfunction
	P1336	CKP Sensor (OBD) or Flywheel Malfunction
	P1400	EGR Valve (and Canister) Control Solenoid Valve Malfunction
	P1401	EGR Temp. Sensor Circuit Malfunction
	P1402	EGR System Malfunction, High Flow
	P1440	EVAP Control System, Small Leak
	P1441	Vacuum Cut Valve Bypass Valve Malfunction
	P1443	Canister Control Vacuum Check Switch Malfunction
	P1444	Purge Control Valve or Solenoid Valve Malfunction
	P1445	Purge Volume Control Valve Malfunction
	P1446	EVAP Vent Control Valve Malfunction
	P1447	EVAP Purge Flow Monitoring Malfunction
	P1448	EVAP Vent Control System Malfunction
	P1550	TCC Solenoid Valve Malfunction
	P1605	A/T Diagnosis Communication Circuit Malfunction
	P1705	TPS Voltage Input to A/T Too High or Low
	P1706	Park/Neutral Switch Circuit Malfunction
	P1760	Overrun Clutch Solenoid Valve Malfunction
	P1775	TCC Solenoid Valve Circuit Malfunction
	P1776	A/T TCC Slip Detected During Lock-Up
	P1900	Cooling Fan Circuit Malfunction

