

Last Modified: 11-2-2015	6.6 M	Doc ID: RM00000120Y02BX
Model Year Start: 2013	Model: Venza	Prod Date Range: [05/2012 -]
Title: THEFT DETERRENT / KEYLESS ENTRY: ENGINE IMMOBILISER SYSTEM (w/o Smart Key System): REGISTRATION; 2013 MY Venza [05/2012 -]		

3. REGISTRATION OF ADDITIONAL KEY

Screenshot by al tech page

(a) Additional registration (Procedure "B"):

HINT:

- A maximum of 5 key codes can be registered.
- Registration mode will end if any step is not completed within the specified time.
- When the ignition cylinder or the key cylinder set is replaced, remove the transmitter module from the original master key. Then install this transmitter module to a new key and use the new key as the master key. If necessary, use this master key to register other keys.

NOTICE:

When the ignition key cylinder has been replaced, locking and unlocking doors are possible with the new master key transmitter module (removed from the original master key). However, the new master key will not be able to lock and unlock doors through the door key cylinder. Keep the original master key. If the battery in the new master key transmitter module fails, the original master key can be used to lock and unlock doors through the door key cylinder.

Additional Registration

PROCEDURE	TIME TO COMPLETE OPERATION	SECURITY INDICATOR LIGHT CONDITION
1. Start	-	Blinking HINT: Until first key is inserted
2. Insert the already registered master key into the ignition key cylinder and turn the ignition switch to ON.	-	OFF
3. Techstream operation Enter the following menus: Body Electrical / Immobiliser / Utility / Key Registration HINT: After completing the above operation, proceed to the next step in accordance with the prompts on the Techstream screen.	Within 120 sec.	ON
4. Remove the master key.	Within 20 sec. HINT: After the Techstream instruction	ON
5. Insert the key to be registered in the ignition key cylinder.	Within 10 sec.	Blinking
6. Wait for 60 sec. after the key is registered. HINT: The security indicator light goes off.	-	OFF
7. Remove the key.	-	Blinking
8. End		

HINT:

- A brief outline of a key code registration procedure is shown above. For detailed information, refer to the Techstream screen.
- When the engine immobiliser system is operating normally and the key is pulled out, the security indicator light blinks continuously.
- If the key code registration has failed in automatic key code registration mode, code 2-1 will be output through the security indicator light. Trying to re-register an already registered key will cause code 2-2 to be output when the key is inserted. If the number of registered key codes exceeds the maximum limit, code 2-3 will be output through the security indicator light. The details are shown in procedure "A".