

<b>Last Modified:</b> 1-7-2022	6.10:8.0.50	<b>Doc ID:</b> RM0000059EV002X
<b>Model Year Start:</b> 2014	<b>Model:</b> RAV4 EV	<b>Prod Date Range:</b> [09/2013 - ]
<b>Title:</b> COOLING: WATER PUMP WITH MOTOR (for HV Battery): REMOVAL; 2014 MY RAV4 EV [09/2013 - ]		

## REMOVAL

### 1. REMOVE DC/DC CONVERTER COVER ASSEMBLY RH INFO


### 2. REMOVE UPPER NO. 1 FLOOR BOARD INFO

### 3. DRAIN COOLANT (for HV Battery)


INFO

### 4. REMOVE WATER PUMP WITH MOTOR RH

(a) Disconnect the connector.




(b) Disconnect the No. 1 EV water pump hose and No. 2 EV water pump hose.



(c) Remove the water pump with motor RH from the bracket.

### 5. REMOVE WATER PUMP WITH MOTOR LH

(a) Disconnect the connector.



(b) Disconnect the No. 3 EV water pump hose and No. 4 EV water pump hose.

(c) Remove the water pump with motor LH from the bracket.

