



Headlight (LHD)



Key Reminder (LHD w/o Entry & Start System)



Front Fog Light (LHD)


Rear Fog Light (LHD)

9


10

11


12

E22(A), E108(A)
Main Body ECU


Automatic Light Control (LHD) and Light Auto Turn Off System (LHD)




Interior Light (LHD)



Door Lock Control (LHD)



Door Lock Control (LHD)



Back Door Opener (LHD)

E22(A), E108(A)
Main Body ECU

Wireless Door Lock Control (LHD w/o Entry & Start System)

(BAT)
10A
ECU-B
NO. 1

Legend:
*24 : w/ Entry & Start System
*25 : w/o Entry & Start System
*31 : H/B, W/G
*32 : S/D
*33 : H/B
*34 : W/G
*35 : w/ Tire Pressure Warning System

- *24 : w/ Entry & Start System
- *25 : w/o Entry & Start System
- *31 : H/B, W/G
- *32 : S/D
- *33 : H/B
- *34 : W/G
- *35 : w/ Tire Pressure Warning System